

# Assembly Instructions

## The Bubwith

The most important thing when assembling the house is that the ground on which the unit is to stand **must be level**. If the ground is not level the unit will not be square and the unit cannot be correctly assembled.

1/ While holding the side panel and end panel together insert the 75mm coach screw provided into the top hole from the outside in the corner where both panels meet, as shown in Picture 1. (all holes are pre-drilled

2/ Insert the bottom screw in the same manner as the top screw. Tighten screws.

3/ Repeat this procedure with the opposite side panel panel.

4/ The floor can now be slid into position, resting on the support blocks on the front and side panels, as shown in pic 2

5/ The front of the house can now be placed into position making sure that the bottom frame sits on the front of the floor. Once into position the panel can be screwed through inside panel into the frame of the side panel as in pic 3 & 4. The opposite side panel can be secured in the same manner.

6/ The front wire panel with the door can now be placed into position and secured with the 4 x 60mm screws as shown in pic 5, repeat this procedure on both corners.

7/ The roof can now be placed into position as shown in pic 6. The roof should fit like a shoe box lid.

### FITTING THE EXTENSION RUN

1/ If you have a unit supplied with the extension run the front panel has no wire or door and is placed into position and secured as in No 6 above.

2/ Attach the extension side panel to the front panel using the 4 x 60mm screws as shown in pic 7. Repeat this procedure with the opposite side.

3/ Place the front wire panel with the door into position and screw into the side panels as shown in pic 8. The wire roof panel can then be placed on top of the extension run as shown in pic 9.

4/ the handles can now be screwed into position as shown in pics 10 & 11.

Your house should now be complete and give you many years trouble free operation.



1



6



2



7



3



8



4



9



5

10

11

