

# Assembly Instructions

## The Escrick and Thorganby

The most important thing when assembling the house is that the ground on which the unit is to stand **must be level**. If the ground is not level the unit will not be square and the unit cannot be correctly assembled.

1/ Place floor on level surface and then place one side and the back together as shown in Picture 1.

2/ While holding the back and side together insert the coach screw provided into the top hole from the outside in the corner where the back and side meet. A gentle tap with a hammer to start the screw is recommended.

3/ Insert bottom screw in same manner as the top screw. Tighten the coach screws with a spanner.

4/ Repeat this procedure with the front, and then place the side panel in last Picture 2.

5/ The removable side panel can be left in or out of the side during assembly as in picture 3. All panels must now be screwed to the floor as shown in pic 8. All holes are pre-drilled (there is no removable side panel in the Thorganby)

6/ The perch hanger bars can now be dropped into the hangers pic 4. Place the perches onto the top of the bars pic 5. The Thorganby Perch hangers can now be screwed to the side panels positioned to the black marker lines on each side panel

8/ Place the the roof section making sure that the roof spars sit on top of the top of the side as in Pic 6 and lower into place. Repeat this with the other side. Once in place screw both roof sections onto the frame of the front and rear panels. Finally place the roof weather board on the top of the apex and screw into place through board into the roof as in picture 7

9/ Finally nail the the four corner latts to each corner as shown in picture 9.

10/ Your unit should now be fully assembled and give you and your poultry many trouble free years of use.

**Steve Fisher Woodworking**

**Tel: 01757 289786**

**[www.stevfisherwoodworking.co.uk](http://www.stevfisherwoodworking.co.uk)**



**PICTURE 1**



**PICTURE 6**



**PICTURE 2**



**PICTURE 3**



**PICTURE 7**



**PICTURE 4**



**PICTURE 8**



**PICTURE 5**



**PICTURE 9**



## Fixing Of The Nest Box

Place the end panel over the nest box as shown in pic 1



Make sure that the roof of the nest box sits tight up to the frame as shown in pic 2



Finally screw the nest box to the frame with the screws provided through the two pre drilled holes on both sides